



Sony Ericsson Xperia Mini Pro SK17i Touch Screen and LCD Display Replacement

Sony Ericsson Xperia Mini Pro SK17i Touch Screen and LCD Display Replacement.

Written By: ZFix



INTRODUCTION

This video tutorial will help you if you want to change / replace broken Touch screen & LCD Display.

[Please SUBSCRIBE to my channel ツ](#)

[video: <http://youtu.be/LF5v0x0DkdE>]



TOOLS:

- [Tweezers](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [T5 Torx Screwdriver](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 03:03:17 AM.